


**TO CUSTOMERS:**

Thank you for purchasing the **LILLIPUT** liquid crystal display (LCD) TV. This product employs new technology, latest electronic circuitry, high quality TFT, TFD LCD modules, and is precisely manufactured. It is a new vision with modern style without radiation. It is also easy to carry and use.

Please read this handbook before operating your TV set. It will be of great help if you have any difficulties in operating.

1. Do not remove the rear panel of this product. Touching high voltage parts inside the cabinet can result in electric shock and/or damaging the unit. If in need of service please call a qualified technician.
2. Do not insert or drop metallic objects into the case through the air vents, for it may cause serious damages.
3. Do not expose this product directly to sunlight, dust, heat sources or humid conditions.
4. Keep off strong light while using this product, so as to obtain the clearest and the most colorful picture.
5. Do not seriously impact or drop onto the ground.
6. While plugging the power cord into a socket be sure to keep the power switch at OFF position.
7. If you do not want to use this product for a long time, unplug the power cord and the Antenna cable as a safety precaution.

**MAJOR CONTROLS & CONNECTORS:**



- 1. DC 12V    2. A/V INPUT    3. CH-    4. CH+    5. CABLE TV INPUT    6. ROD-ANTENNA
- 7. POWER OFF/VHF/UHF SELECTOR    8. BRIGHT    9. VOLUME.    10. CAR STAND BOLT
- 11. CONTRAST & COLOR (two holds on the rear cover)

## OPERATION

**ATTENTION:** When connecting the power, make sure the terminal electric poles are as follows: the inner pole = “+” and the outer pole = “-” .

1. Plug the power cord into DC 12V jack after the AC adapter is in the main socket.

The input voltage range from DC 10.5 to 12V can be used. This product also provided with an AC adapter.

2. Turn the power on and select the VHF or UHF in your will. VHF 1-12 channel is shown with a green bar, and UHF 13-68 channel is a red one.
3. Adjust the length and direction of the antenna rod to obtain the best picture and sound. If the antenna rod can not receive clear TV signal, connect the TV set to an outdoor antenna or to the cable.

4. Press CH+ or CH- to search automatically the desired program. The tuning bar can move right or left while searching. When your unit catches a program, the bar will stop and disappear a few seconds later
5. Adjust the brightness and volume controls to get the best picture and sound.
6. Link your TV set through the A/V jack with a VCD player, tape recorder, electric camera or the other signal sources, you may enjoy your wonderful pictures.
7. The picture color and contrast of the unit are preset in the factory. Don't adjust them too often and be sure to use the right size screwdriver when needed.

**MAIN CHARACTERISTICS:**

MODEL	<b>PTV-60C</b>
SCREEN SIZE	6"
DOTS H×V	480×240
SYSTEM	PAL4.43、NTSC3.58
POWER (V).	DC: 11-13V
CONSUMPTION	≤8W
A. OUTPUT	>150mw
V. IN	1V <sub>p-p</sub> ; 75Ω
WEIGHT	500g (not including the accessories)
SIZE	165×132×43 (mm)